Frequently Asked Questions

Q1 What is the default login details for the router?

(if you didn't change the details in the setup wizard)

Username: admin Password: admin

Please note: it is a security risk to leave the default password as admin & admin. It is highly recommended to set your own unique password.

Q2 I only received 1 LAN cable in the box but I need 2 to do the setup. Am I missing a cable?

No. The LAN cable supplied with your router is to connect your computer/laptop to the router during setup. The ONT device should have came with a LAN cable for connecting it to the WAN port on the back of the router. If you can't find a second LAN cable to connect your router to your laptop for the setup, you will need to do the setup over Wi-Fi.

Q3 What if the hardware connection keeps failing on step 1?

Please contact your ISP and verify that your ONT device and Fibre line is active

Q4 I did the setup over Wi-Fi but got disconnected on the Wireless Network step of the wizard. What do I do now?

If you changed your Wi-Fi username and password: Open your Wi-Fi settings on the device you used to setup the router. Select the new Wi-Fi name you set from the list of available networks and enter the password. Once connected reopen the webpage at 192.168.0.1 to complete the setup.

If you changed only your <u>Wi-Fi password</u>: Open your Wi-Fi settings on the device you used to setup the router. Select the router's Wi-Fi name and forget the network. Now reselect your router's Wi-Fi name and type in the new Wi-Fi password you set on the wizard. Once connected reopen the webpage at 192.168.0.1 to complete the setup.

Q5 What do I do if while in the Router web interface my browser locks up / goes white / says undefined?


If this happens, please clear your browser cookies & cache and reload the page.

Use screws of up to 4mm (head radius)

Drill Here (10,9 cm apart) to mount your router to the wall

8,5 mm

Router Wall Mounting Guide



DIR-612

Quick Install Guide

Use this step-by-step guide to set up your router

Package Content





DIR-612 Router





Power Supply






RJ-45 Ethernet Cable





Quick Install Guide









Warranty cards

Start Here











Connect the grey RJ-45 Ethernet cable to any LAN port at the back of the router and the other end into your PC LAN port.



Use the default Wi-Fi SSID and password (WPA PIN) printed on the bottom of the router to connect your Wi-Fi enabled device to the router



D-Link Assistant App

Download and use the D-Link Assistant App to setup and manage your router settings.



Launch an Internet browser (Google Chrome, Firefox, Internet Explorer, Safari, etc.) on your connected device.

In the URL web address field, type 192.168.0.1 and press enter.

The Setup wizard will start automatically. Please follow the steps of the wizard to finish the configuration of the router

When you launch the


first time the setup

router interface for the

wizzard will automatically

launch. Select "Start"

to begin the set up process.



If you are using the D-Link Assistant App to complete the setup:

Step 1.

Download the App from the google playstore and launch the app.






Step 2.

Connect to the Router's Wi-Fi with the details located on the sticker on the

Launch the D-Link Assistant App. The App will automatically detect your router. Complete the configuration by following all the steps of the setup wizzard.



START

06

Maybe your language is English?

Select the language for the interface. Select "YES" to set English as your prefered language.

NO

Select "continue" to continue configuring the router with the setup Wizard.

You can use the advanced settings or continue configuration with the Wizard

ADVANCED SETTINGS

80

Click the dropdown and set "Wired Connection" as uour connection method

Connection method

Wired Connection ▼

Leave the work mode as "Router" and click next to proceed to the next step.

Connection method

Wired Connection

Work mode

Router



Press the "Scan" button to automatically detect which WAN connection to use.

Leave the three tick boxes for Clone MAC. VLAN and Ping unticked Internet connection type

Select the connection type... ▼

Scan

Clone MAC address

Use VLAN

Ping

This step allows you to set the Wi-Fi name and Password for your Wi-Fi network.

Click next to proceed.

Wireless Network 2.4 GHz

✓ Enable

✓ Broadcast wireless

Network name

DIR-612-XXXX

Password

BACK

Both the IPTV and VoIP steps can be skipped by clicking "next".

IPTV & VoIP

BACK

Set a password for

logging into the router and confirm it below.

This password allows you to log into the router if you want to change any settings.

Click next to proceed.

Changing web-based interface password

User's interface password

Password confirmation

BACK

Please make sure to write down all the details on this page & keep it somewhere safe for you to refer back to later.

Click "Apply" to finish.

Summary page

Dynamic IPv4 Wi-Fi 2.4 GHz Device Login data

BACK

